



# Skil X-Drive 18V Cordless Drill Model No. 2887

## Quick Reference Gauge Replacement

This guide will show how to remove the Gauge in order to replace it or continue further to replace other components.

Written By: Michael



## INTRODUCTION

Whether you need to replace the gauge or remove it to in order to continue to get to the rest of the drill, this guide will show you how to.

## Step 1 — Remove Gauge



- Hold drill upright with one hand and slide the gauge backwards to remove it with the other.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-08-31 08:34:23 AM.